



**Wire Cup & Saucer Holders**

O. #50-0755 Gold finish #50-0755W Ant. white finish  
P. #50-0708 Brads #50-0708S Silver  
Q. #50-0740W 4" wide and 38" high. Holds 4 cup & saucer sets.  
R. #50-0740W 4" wide and 38" high. Holds 4 cup & saucer sets.  
S. #50-0740W 4" wide and 38" high. Holds 4 cup & saucer sets.  
T. #50-0740W 4" wide and 38" high. Holds 4 cup & saucer sets.

### Wrought Iron Cup & Saucer Holders



- M. #50-0764 Platinum brass wire. 6 1/4" W x 8" H.  
L. Twisted wire. 4" W x 10 1/2" H.  
**Wire Cup & Saucer Holders**  
K. #43-0018 Clear #43-0018G Gold  
J. #43-0005 Compact clear plastic stand.  
**Plastic Cup & Saucer Stands**  
H. #50-0709 Brads #50-0709S Silver  
I. #50-0307 For two cups and saucers. Measures 9 1/2" X 5 1/2" X 6 1/2".  
**Wire Cup & Saucer Stands**  
G. #105 Elevates saucer behind cup. 4 1/4" wide x 6" deep x 4 1/4" high.  
F. #114 For demitasse cup & saucers. 3 1/2" wide x 4" deep x 2 3/4" high.  
**Wood Cup & Saucer Stands**  
E. #50-0707 6 1/2" high.  
D. #50-0706 Twisted brass wire. 7" high.  
**#50-0703 for demitasse**. 2" deep x 4 1/4" high.  
C. #50-0701 Plain wire. 3" deep x 6" high.  
B. #50-0702 Twisted wire. 3" deep x 6" high.  
**#50-0308 for demitasse**. 3 1/2" deep x 6" high.  
A. Brass plated cup & saucer stands.  
**Brass Cup & Saucer Stands**  
#50-0306 4 1/4" deep x 7 1/2" high.  
#50-0307 4 1/4" deep x saucer stands.  
#50-0308 3 1/2" deep x 6" high.  
#50-0309 3 1/2" deep x 6" high.  
#50-0310 3 1/2" deep x 6" high.



### Cup & Saucer Holders